

Porsche 987/Cayman Exhaust Tip Tech Note

Thank you for purchasing your new Porsche 987/Cayman Tip , below you will find installation instructions to help you complete the installation.

Step 1- Remove the factory tip by loosening the 13mm Bolt, in a twist motion pull and twist out the tip.

Step 2 – When installing the new tip, notice the inner shim inside the tip, the opening of the shim should not be aligned with the opening of the exhaust inlet , basically as long as it's not aligned with the tip opening (clamping part) you will be ok. (see picture below)

Step 3 – Install the tip on the car, tip shim should not stick out it must be at least par with the inside edge. Tighten the 13mm bolt and you're done. Enjoy



Questions? Please use "Submit Question" form in our [Tech Center Section](#)

Maxspeed-Motorsports.com Copyright 2009