

# 996 Turbo Boost Hose Kit Installation

## Instructions

Thank you for purchasing your new Porsche 996TT Boost Hose Kit, below you will find installation instructions to help you complete the installation.

### Tools Needed

Philips Screwdriver

Torx Screwdrivers

8 & 10mm socket with ratchet

Floor Lift

**Step 1-** You will need to remove the bumper in order to install the two top hoses. Start by removing the 2 tail lights there are 2 screws on each side of the tail lights , once the 2 screws are removed the taillight should come right off. Remove the top retaining bracket by removing the 4 screws, this bracket is located between both taillights.

**Step 2 –** Raise the car and secure both sides with jack stands. Remove both rear wheels. Remove both inner plastic on the bumper side. Remove all 6 screws at the bottom of the bumper, underneath the bumper. With the help of someone pull out the bumper and detach the electrical connection for the license plate lights.

**Step 3 –** Remove the lock clip on the driver's side boost hose on the engine side, remove the lock clip on the intercooler side and pull out the hose , repeat the same procedure for the passenger's side hose.

**Step 4-** Loosen up the clamp on the turbocharger side hose , remove the lock clip on the intercooler side and pull out the hose, repeat the same procedure for passenger's side.

**Step 5-** Re-install everything in reverse order, but use the included T-Bolt clamps to secure the hoses to the turbo.

For the lower left hose (driver's side) it is ok to flex the hose while tightening the clamp on the turbocharger , silicone is flexible it is normal for the hose to point more towards the left once you tighten it with the clamp it will be secured properly.

Happy Motoring

Questions? Please use "Submit Question" form in our [Tech Center Section](#)

Maxspeed-Motorsports.com Copyright 2010