

Porsche 996/997 Performance Air Intake Hose Installation Instructions

Thank you for purchasing your new Performance Air Intake Hose for your Porsche , below you will find installation instructions to help you complete the installation.

Tools Needed

Screwdriver Set

Step 1- Your OEM air intake hose is held in place by 3 Hose Clamps, loosen up the 3 clamps and remove the OEM Air Intake hose from the throttle body and airbox.

Step 2- You will need to re-use your factory worm clamps, start by installing the small black cap over the airbox internal muffler and secure it with the smallest hose clamp previously removed.

Step 3- At this point you're ready to install the Red Intake Hose, our silicone hoses are flexible but they are 4-ply which are more on the hard silicone side, don't be afraid to flex and bend the hose, you will most probably need to use some force to bend it and get it installed properly. Use some lubricant at both ends inside edges so that its easier to install this hose on the air filter box and throttle body this will help you insert the hose at both ends. Insert both clamps around the hose and Install the RED Silicone hose , on the 996 models you will need to loosen up the 13mm bolt that retains the airbox on the 996 models this will allow for more movement of the airbox, you will most probably need to lift the box to get it at an angle to fit the hose in, for the 997 you must remove the center pin that holds the box in place so that you can move the box, the center pin is located right in front of the trunk latch. Note: that once you have the hose fitted you must rotate the red silicone hose to obtain the correct angle and position of this hose, (we have marked the hose with two black lines, these two black lines are guides that should be on the center of throttle body and center or air filter see pictures below) once you have found the correct position you may have to apply pressure by pushing the box so that the hose seals properly and at the same time you tighten your worm clamps.

Note that a small kink on the interior side of the hose once installed is normal see picture below.





Congrats you're done Enjoy.

Questions? Please use "Submit Question" form in our [Tech Center Section](#)

Maxspeed-Motorsports.com Copyright 2010