

# NHP Exhaust 987.1 987.2 Boxster Cayman Exhaust Mufflers Installation Instructions.

Thank you for purchasing your new Porsche 987 NHP Exhaust System, below you will find installation instructions to help you complete the installation. Note we always recommend professional installation.

## **Tools and equipment needed to complete the work.**

Floor Jack (if commercial lift is not available)

2 x Jack Stands if using a Floor Jack.

Ratchet set and sockets 3/8" drive and 1/2" Drive.

Torx screwdriver

Metric Key set.

## **Important safety instructions.**

Only work underneath the car if the car is safely supported with appropriate Jack Stands. Only work on exhaust parts when the engine is cold and exhaust completely cooled down.

Shown below is pictures from an installation on a 2007 Boxster, it is the same procedure for any Boxster or cayman 987.

**Step 1-** Loosen up rear wheels lug bolts, raise the rear of the car and support the rear of the car safely using appropriate jack stand, remove wheel lug bolts and remove both rear wheels. Locate the heat shield inside the wheel wells and remove them.



**Step 2-** Using a few extensions with a ratchet and 13mm socket remove the 3 bolts that connect the muffers to the headers.



**Step 3** – Once you have removed the 3 bolts that connect the muffler to the headers, all you have left is to loosen both muffler supports and the exhaust will come down in one complete section. If you're working on the floor with the car raised and supported on jack stands use the floor jack to support the exhaust, in other words put the floor jack under the exhaust muffler on the left or right side. Locate both muffler supports and remove the 2 bolts on each muffler support and your done drop the exhaust with the help of your floor jack.



**Step 4-** You are now ready to install the NHP Exhaust. Start by installing both your gaskets on the exhaust headers.





**Step 5-** Install both the left and right side mufflers without tightening any of the bolts and support your mufflers with jack stands.





**Step 6-** With the mufflers not completely tightened on the headers/muffler flanges insert the Y-Pipe without tightening the Y-Pipe clamps.





**Step 7-** Now tighten the bolts between the headers and mufflers.





**Step 8-** Install the Muffler supports, please see pictures below on how the supports should be assembled and installed.











**Step 9-** Now position Y-Pipe at your desired angle , tighten both clamps and finally install the exhaust tip.

The muffler installation is complete.

Questions? Please send an [e-mail](#)

Maxspeed-Motorsports.com Copyright 2011